


feb 2006



benchmark = competitors values (sometimes against own product).

Why QFD → fast way to translate customer requirements into specifications. The QFD is also used for compliance checking on the same area. (other way round).

relationship ; ② strong → 9.

① medium → 3

③ weak → 1

correlation ; ②

①

X

XX

1) i) house of quality (user req → product req)

↳ 2) Parts deployment (product req → tech req)

↳ 3) Process planning (techreq → production req)



4) Production planning (production req → machine settings).

2a) private / military / commercial.

d) S

cheap ops costs.

short runway length.

high ceiling (avoid weather)

W

low payload.

low speed.

no antishad.

O

leader of (new) market

large market



(invariability of product).

T

low demand for product

new design (behavior unknown)

5 c) reliability block diagram;



e)